Table of contents

D.,, f 11	Feedrate 30
Preface 11	Turret indexing (tool changing) 30
Prerequisites 11	Turret station and offset selection 31
Basic machining practice experience 11	Coolant 32
Math 12	Other possible programmable functions 32
Motivation 12	Tailstock 32
Controls covered 12	Programmable steady rest 32
What about conversational controls? 13	Bar feeders and chuck activation 32
Controls other than Fanue 13	Part catcher 33
Limitations 14	Tool touch off probe 33
Instruction method 14	Automatic tool changing systems 33
Scope 14	Exceptions to X axis 33
Key Concepts approach 15	A quick fix 33
Lesson structure 15	Gang type turning centers with cutting tools on
Practice, practice! 15	both sides of the spindle centerline 34
Key Concepts and lessons 15	Center cutting axis 34
1: Know your machine from a programmer's	What else might be programmable? 34
viewpoint 15	Key points for Lesson One: 35
2: You must prepare to write programs 15	I 2 II. I II. T C C I
3: Understand the motion types 16	Lesson 2: Understanding Turning Center Speeds
4: Know the compensation types 16	and Feeds 36
5: You must provide structure to your CNC	The two ways to select spindle speed 37
programs 16	When to use constant surface speed mode 38
6: Special features that help with programming	When to use rpm mode 39
16	How to specify a maximum speed for the
7: Know your machine from a setup person or	constant surface speed mode 41
operator's viewpoint 16	A potential limitation of constant surface speed
8: Know the three basic modes of operation 16	41
9: Understand the importance of procedures 16	The two ways to specify feedrate 42
10: You must know how to safely verify	When to use the feed per revolution mode 42
programs 16	When to use the feed per minute feedrate mode
Enjoy! 16	43
	An example of speed and feed usage 43
Key Concept 1: Know Your Machine	Key points for Lesson Two: 44
•	Lesson 3: General Flow Of The CNC Process 45
From A Programmer's Viewpoint 17	Companies that use CNC turning centers 45
Lesson 1: Machine Configurations 19	What will you be doing? 46
Types of CNC turning centers 19	Flow of the CNC process 46
Universal style slant bed turning center 19	Study the workpiece drawing 46
Directions of motion (axes) for a universal	Decision is made as to which CNC machine to
style slant bed turning center 20	use 46
Live tooling for a universal style slant bed	The machining process is developed 47
turning center 21	Tooling is ordered and checked 47
Other types of CNC turning centers 23	The program is developed 47
Chucking style slant bed turning center 23	Setup and production run documentation is
Twin spindle horizontal bed turning centers 23	made 47
Sub-spindle style turning centers 24	Program is loaded into the CNC control's
Vertical single spindle turning centers 25	memory 47
Twin spindle vertical turning centers 26	The setup is made 47
Gang style turning centers 26	The program is cautiously verified 48
Swiss-type CNC turning centers (also called	Production is run 48
sliding headstock turning centers) 27	Corrected version of the program is stored for
Programmable functions of turning centers 28	future use 48
Spindle 28	Key points for Lesson Three: 48
Spindle speed 28	· -
Spindle activation and direction 28	
Spindle range 29	

Lesson 4: Visualizing The Execution Of A CNC	Stylus use 81
Program 49	Procedure to use a tool touch off probe 82
Program make-up 50	Determining and entering the work shift value 85
Method of program execution 50	Using geometry offsets with work shift to assign
An example of program execution 50	program zero (your 2nd choice) 87
The CNC program to machine the 2.875	Understanding the measure function 88
diameter 51	Using geometry offsets without work shift to
Sequence numbers 52	assign program zero (your 3rd choice) 91
	Assigning program zero in the program with G50
A note about decimal point programming 52	or G92(your last resort) 93
A decimal point tip 53	
Other mistakes of omission 53	Determining the program zero assignment values
Modal words 53	for each tool 94
Initialized words 53	Programming format when program zero is
Letter O or number zero? 53	assigned in the program 95
Word order in a command 53	Making the machine more efficient when
Key points for Lesson Four: 54	assigning program zero in the program 97
7 5 D 7 4 1 Tl . D 1	Key points for Lesson Seven: 98
Lesson 5: Program Zero And The Rectangular	I among Or Internal Acceptions To Decree and incompany Wards
Coordinate System 55	Lesson 8: Introduction To Programming Words
Graph analogy 55	101
More about polarity 56	Words allowing a decimal point 101
Wisely choosing the program zero point location	O 102
57	N 102
In X 57	G 102
In Z 57	X 102
62	Y 102
Absolute versus incremental positioning	For turning centers equipped with a Y axis (not
movements 62	many turning centers have this function) this letter
Another way to specify absolute and incremental	address specifies absolute positioning along the Y
positioning 62	axis. A decimal point is allowed with the Y word.
A decimal point reminder 63	<u>-</u>
	102
Key points for Lesson Five: 64	Z 102
Lesson 6: Determining Program Zero Assignment	U 103
Values 65	W 103
Program zero must be assigned independently for	C 103
each cutting tool 65	R 103
Understanding program zero assignment values 67	I & K 103
	F 103
What is the zero return position? 67	E 103
Program zero assignment values 67	S 104
How do you determine program zero	T 104
assignment values? 69	M 104
Will you really have to determine all of these	P 104
values? 72	Q 104
Other considerations that affect program zero	L 105
assignment values 72	EOB (end of block character) 105
How accurate are the program zero assignment	,
values? 72	/ (slash code) 105
Trial machining 73	G and M codes 106
Another advantage of tool touch off probes 73	G codes 106
Tool wear 73	G code limitation: 106
Replacing dull tools during a production run 73	Option G codes 106
Using cutting tools from one job to the next 74	What does initialized mean? 106
Key points for Lesson six: 74	What does modal mean? 106
Key points for Lesson six. 74	The most popular G codes 106
Lesson 7: Four Ways To Assign Program Zero 77	Common M codes used on a CNC turning center
Understanding geometry offsets 77	108
How geometry offsets are instated 78	Key points for Eight Seven: 109
The four most common ways to assign program	Key points: Key Concept one 110
zero 79	, r, compercine 110
Using a tool touch off probe to assign program	
zero – also called a tool setter (your 1st choice) 80	

Key Concept 2: You Must Prepare To Write Programs 113

Preparation and time 113 Preparation and safety 114 Typical mistakes 115 Syntax mistakes 115 Motion mistakes 115 Mistakes of omission 115 Process mistakes 116

Lesson 9: Preparation Steps For Programming 117

Prepare the machining process 117 Develop the needed cutting conditions 119 An example 120 Cutting conditions can be subjective 121 Do the required math and mark-up the print 122 Marking up the print 125 Doing the math 126 Check the required tooling 129 Plan the work holding set-up 130 Other documentation needed for the job 131 Production run documentation 131 Program listing 131 Is it all worth it? 131

Key Concept 3: Understand The Motion Types 135

What is interpolation? 135

Key points for Lesson Eight: 131

Lesson 10: Programming The Three Most Basic Motion Types 139

Motion commonalties 139 Understanding the programmed point of each cutting tool 139 G00 Rapid motion (also called positioning) 142 What is a safe approach distance? 144 What about feed-off distance? 145 G01 linear interpolation (straight line motion) 145 Using G01 for a fast feed approach 148 G02 and G03 Circular motion commands 149 Specifying a circular motion with the radius word 149 Circular motion with directional vectors (I and What's wrong with this picture? 152

Key Concept 4: Know The Compensation Types 157

Key points for Lesson Ten: 155

More on interpreting tolerances 157 How design engineers specify tolerances 158 High and low limit specified 158 Plus or minus tolerance 158 Plus one value, minus another 159 Is a measured workpiece attribute on-size (acceptable)? 159 What if a measured dimension is not on-size (not acceptable)? 160

More on the target value 160 One more consideration - tool wear 161

Lesson 11: Introduction To Compensation 163

What is compensation and why is it needed? 163 The initial setting for compensation 164 When is trial machining required? 164 What happens as tools begin to wear? 165 What do you shoot for? 165 Why do programmers have to know this? 165 Understanding offsets 165 Offset organization 166 Offset pages on the display screen 166 How offsets are instated 168 Key points for Lesson Eleven: 168

Lesson 12: Geometry Offsets 169

Review of reasons for using geometry offsets to assign program zero 169 How geometry offsets work 169 The total program zero assignment value 170 Warning about the machine lock feature: 171 Minimizing program zero assignment effort from job to job 171 So when do you clear geometry offsets? 173 Key points for Lesson Twelve: 173

Lesson 13: Wear offsets 177

Which dimension do you choose for sizing?

How wear offsets are programmed 178 What if my machine doesn't have geometry offsets? 178

What about wear offset cancellation? 179 How wear offsets are entered 180

Which is better, INPUT or +INPUT? 182 What if my machine doesn't have a +INPUT soft key? 182

Sizing in a tool after it has just been placed in the turret 182

Sizing in a new tool with trial machining 184 What causes the initial deviation? 184 Dealing with deviations caused by tool wear 185 After a dull tool is replaced 186

What if my machine has a tool touch off probe? 187

Consistently replacing inserts 187 Consistently indexing inserts 188 Minimizing the need for trial machining 189 Going from job to job 189

When do you clear wear offsets? 189

A more complex example 189

Running the first workpiece – one tool at a time

Tool number one: Rough face and turn tool

Tool number Two: Finish face and turn tool

Tool number Three: 0.125 grooving tool 192 Completing the production run 192

Tool number one: Rough face and turn tool 192

© CNC Concepts, Inc.

Tool number Two: Finish face and turn tool

Tool number Three: 0.125 grooving tool 193

A reminder about up-coming jobs 193

A reminder about target values 193

Secondary wear offset applications 193

Flip jobs 193

Two or more critical diameters 194

Unwanted taper 194

Grooving into different areas of the workpiece

Key points for Lesson Thirteen: 194

Lesson 14: Tool Nose Radius Compensation 195

Keeping the cutting edge flush with the work surface at all times 197

When to use tool nose radius compensation 198 Steps to programming tool nose radius compensation 198

Instating tool nose radius compensation 198 Programming motion commands to machine the workpiece 199

Canceling tool nose radius compensation 200

An example program 200

Tool nose radius compensation from a setup person's point of view 201

What if my machine does not have geometry offsets? 203

What if I forget to enter tool nose radius compensation values? 203

What if I enter tool nose radius compensation values into wear offsets? 203

What if I enter tool nose radius compensation values into both the geometry and wear offsets? 203

Programming tool nose radius compensation value entries 203

Another example program showing tool nose radius compensation 203

Key points for Lesson Fourteen: 205

Key Concept 5: You Must Provide Structure To Your CNC Programs 207

Lesson 15: Introduction To Program Structure 209

Objectives of your program structure 209

Reasons for structuring programs with a strict and consistent format 209

Familiarization 209

Consistency 210

Re-running tools in the program 210

Efficiency limitations 212

Machine variations that affect program structure 213

M code differences 213

G code numbering differences 214

Turret variations 215

How do you determine a safe yet efficient index position? 215

What if my machine doesn't have geometry offsets? 216

A reminder about spindle limiting 217

Choosing the appropriate spindle range 218

Which direction do you run the spindle? 218

How do you check what each tool has done? 218

A possible problem with initialized modes 218

How to use our given formats 219 Key points for Lesson Fifteen: 220

Lesson 16: Four Types Of Program Format 221

Format for assigning program zero with geometry offsets 222

Program start-up format (using geometry offsets)

Tool ending format (using geometry offsets) 223 Tool start-up format (using geometry offsets)

Program ending format (using geometry offsets)

Format for assigning program zero in the program with G50 224

A reminder about the program's starting point and tool change position 224

Program start-up format (assigning program zero in the program) 224

Tool ending format (assigning program zero in the program) 225

Tool start-up format (assigning program zero in the program) 225

Program ending format (assigning program zero in the program) 225

Understanding the formats 225

G Words 226

M Words 226

Other M Words Related to Turning Centers

Other Words In The Format 227

Example programs showing format for turning centers 228

Example when assigning program zero with geometry offsets 228

Where are the restart commands? 229

Example when assigning program zero in the program 230

Where are the restart commands? 231

Suggestions for cycle time improvements. 231

Combine M codes in motion commands 231

Minimize spindle dead time 232

Efficiently programming spindle range changes 235

Minimize spindle reversals 236

Key points for Lesson Sixteen: 236

Key Concept 6: Special Features That Help With Programming 239

Control series differences 240

Lesson 17: One-Pass Canned Cycles 241

Cycle consistencies 241

G90 - One pass turning and boring cycle 242

G92 - One pass threading cycle 243

G94 - One pass facing command 244

Example of G90 and G94 244 Example of G92 command 245	Thread with thread chamfering turned off 273
	Finish the thread before removing workpiece 273
Key points for Lesson Seventeen: 246	Right hand threads versus left hand threads 273
Lesson 18: G71 And G70 - Rough Turning And	Offsetting for threading tools 274
Boring Followed By Finishing 247	Start the tool far enough away from the thread
G71 - Rough turning and boring 247	being machined 274
The two phases of G71 248	Minimum depth-of-cut, final pass depth, and
Understanding G71 command words 250	number of spring passes 274
P word 250	Disabled or modified control functions during
Q word 250	threading 274
U word 250	Tapered threads 275
W word 250	Multiple start threads 276
D word 250	Different format for 0TA, some 0TBs, and 3T
F word 251	controls 278
What about finishing? 251	What about tapping? 278
Example showing G71 for rough turning and G70	Tap in the rpm mode 278
for finish turning 251	Tap in the low range 278
Using G71 for rough boring 253	Use G32 as the motion command for tapping
Limitations of the G71 command 255	278
Different format for 0TA, some 0TBs, 3T, and 18T	Use a tension/compression tap holder 279
controls 256	Keep the approach position 0.2 from the Z
Key points for Lesson Eighteen: 256	surface to tap 279
Losson 10, C72, Pough Egging, C72, Dattown	Key points for Lesson Twenty: 279
Lesson 19: G72: Rough Facing, G73: Pattern	
Repeating, G74: Peck Drilling, And G75:	Lesson 21: Working With Subprograms 281
Grooving 259	The difference between main- and sub- programs
G72 - Rough facing 259	281
Different format for 0TA, some 0TBs, 3T, and	Loading multiple programs 281
18T controls 261	Words used with subprograms 282
G73 - pattern repeating 261	A quick example 282
D word 262	Nesting subprograms 283
I word 262	Applications for subprograms 284
K word 262	Repeated machining operations 284
Example of G73 pattern repeating 263	Control programs 284
Can you use G73 for castings and forgings? 264	Utility applications 284
	Example for repeating machining operations -
Different format for 0TA, some 0TBs, 3T, and 18T controls 265	multiple identical grooves 285
	Example for control program applications - flip
G74 - peck drilling 265 What if I must clear chips between pecks? 266	jobs 287
Different format for 0TA, some 0TBs, 3T, and	Example for utility applications - bar feeder
18T controls 267	activation 288
G75 - grooving cycle 267	Special notes about M99 290
Key points for Lesson Nineteen: 268	Ending a main program with M99 290
Rey points for Lesson Whiteteen, 200	Changing the order of program execution with
Lesson 20: G76 - Threading Command 269	M99 290
X word 269	What is parametric programming (custom macro
Z word 270	B)? 293
What is thread chamfering? 270	Part families 293
K word 270	User defined canned cycles 293
D word 270	Utilities 293
A word 271	Complex motions and shapes 295
F word and E word 271	Key points for Lesson Seventeen: 295
I word 271	Lesson 22: Differences To OTA, OTB, 3T, And 18T
Q word 271	Controls 297
Example program for threading 272	G71 297
Other tips on threading 273	G72 297
When possible, thread in the lowest spindle	G73 297
range 273	G74 298
Thread in the rpm mode (G97) 273	G75 298
Watch out for maximum allowable feedrate 273	G76 298

Subprograms 298 Only one way to specify speed and feedrate What about controls that are not made by Fanuc? Hole machining canned cycles 330 G code differences 299 Polar coordinate interpolation 330 Selecting the main spindle mode 330 Lesson 23: Other Special Programming Features Programming an indexer 330 Example program for an indexer 331 Block delete (also called optional block skip) 301 Programming a rotary axis (C axis) 333 Applications for block delete 302 Angular values 333 Another optional stop 302 Zero return position 333 Trial machining 302 Rapid versus straight line motion 333 Warning about optional block skip applications Program zero assignment 333 Absolute versus incremental 334 Sequence number (N word) techniques) 304 Canned cycles for hole machining 335 Eliminating sequence numbers 304 How do you specify the machining direction? Using special sequence numbers in program restart commands 304 Canned cycle types 335 Documenting your programs with messages in Words used in canned cycles 336 parentheses 306 An example program 336 General information about the job 306 Understanding polar coordinate interpolation Tool information 307 337 At every program stop 307 Other machine types 341 To document anything out of the ordinary 307 Twin spindle turning centers 341 For changes made after a dispute 308 Sub-spindle turning centers 341 Automatic corner rounding and chamfering 308 Swiss-type turning centers (also called sliding Other G codes of interest 310 headstock turning centers) 342 G04 - Dwell command 310 Other G codes 311 **Key Concept 7: Know Your Machine** Key points for Lesson Twenty-Three: 312 From An Operator's Viewpoint 345 Appendix: Special Machine Types And Accessories The need for hands-on experience 346 313 About Key Concept Number Seven 347 Work holding and work support devices 313 Procedures you must know about 347 Work holding devices 313 Machine power-up and power-down 347 Three jaw chucks 314 Sending the machine to its zero return position Collet chucks 317 347 Work support devices 319 Manually moving each axis 347 Tailstocks 319 Manually starting the spindle 348 The tailstock body 319 Manually indexing the turret 348 Tailstock quill 319 Manipulating the display screen 348 Center 320 The position display screen 348 Tailstock alignment problems 320 The program display screen 349 Programming considerations 320 The offset display screen 349 Steady rests 321 The program check display screen 349 Bar feeders 321 Loading and saving CNC programs 349 How a bar feeder works 322 Workholding considerations 322 Lesson 24: Tasks Related To Setup And Running Styles of bar feeders 322 Production 350 How to program for bar feeders 323 A CNC job from start to finish 352 Determining how much to feed the bar 323 Setup documentation 353 The steps to bar feeding 324 Tear down the previous setup and put everything The redundancy of bar feed programming 325 When to program the bar feed 325 Gather the components needed to make the setup Ending a bar feed program 326 354 An example bar feeding program 326 Make the workholding setup 354 Part catchers 328 How To Mount Jaws In The Correct Serrations Live tooling 328 Features of live tooling turning centers (also Machining soft jaws during setup 357 called mill/turn machines) 329 Other devices related to work holding setup Rotating tools 329 359 Special tool holders 329 Assemble cutting tools 359 Precise control of main spindle rotation 329

A reminder about mounting inserts 359 Load cutting tools into the turret and adjust coolant lines 360

Assign program zero for each new tool 360 Enter tool nose radius compensation values (if the programmer uses this feature) 360

Load the CNC program/s 360

Verify the correctness of a new or modified program 361

Verify the correctness of the setup 362

Dry running our example program 362

Cautiously run the first workpiece 363

The most dangerous time 363

Making sure the first workpiece is a good one 364

Machining the first workpiece in our example job 365

Move through the program one tool at a time 367

Upcoming jobs 367

A note about our example job 368

First workpiece inspection 368

Program optimizing 368

Saving corrected version of the program 368

What will you be doing? 368

Production run documentation 368

Remove the previous workpiece 370

Load the next workpiece 371

Activate the cycle 371

Monitor the cycle 371

Clean and de-burr the workpiece 371

Perform specified measurements 372

Make offset adjustments to maintain size for

critical dimensions (sizing) 372

Replace worn tools 373

Clean the machine 373

Preventive maintenance 373

Machine warm-ups 373

Key points for Lesson Twenty-Four: 373

Lesson 25: Buttons And Switches On The Operation Panels 375

The two most important operation panels 375 The control panel buttons and switches 375

Display screen control keys (soft keys) 376

Position display pages 377

Program display pages 377

Offset display pages 377

Program check display pages 378

Other display screen modes 378

The keyboard 379

Letter Keys 379

The slash key (/) 379

Number keys 379

Decimal point key 379

The input key 379

Cursor control keys 379

Program Editing Keys 379

Reset key 379

The machine panel 380

Mode switch 380

Cycle start button 380

Feed hold button 380

Feedrate override switch 381

Rapid traverse override switch 381

Emergency stop button 381

Conditional switches 382

Dry run on/off switch 382

Single block on/off switch 382

Block delete on/off switch (also called optional

block skip) 382

Optional stop on/off switch 382

Buttons and switches for manual functions 382

Axis jogging controls 383

Handwheel controls 383

Spindle control 383

Turret index control 383

Indicator lights and meters 384

Spindle rpm and horsepower meters 384

Axis drive-motor horsepower meter 384

Cycle indicator lights 384

Zero return position indicator lights 384

Optional stop indicator light 384

Other buttons and switches on the machine panel

Other operation panels on your turning center 384

Key Concept 8: Know The Three Basic Modes Of Operation 385

Lesson 26: The Three Modes Of Operation 385

The manual mode 385

The manual data input mode 386

The manual data input (MDI) mode switch position 386

Commanding an MDI zero return 386

The complete procedure to give an MDI

command 387

Commanding an MDI tool change 387

Commanding spindle activation with MDI 387

Other times when MDI is used 388

Can you make motion commands with MDI? 388

The edit mode switch position 388

To make a program in memory the active program (to call up a program) 389

To enter a new program 389

The program operation mode 390

To run the active program from the beginning

Key points for Lesson Twenty-Six: 390

Key Concept 9: Understand The Importance Of Procedures 391

Lesson 27: The Key Operation Procedures 392 Key points for Lesson Twenty-Seven: 402

Key Concept 10: You Must Know How To Safely Verify Programs 403

Safety priorities 403

Operator safety 403 Machine tool safety 404 Workpiece safety 404

Lesson 28: Program Verification 405
Two more procedures 405
Canceling the CNC cycle 405
To cancel the cycle 405
To re-run a tool 406

Verifying a job that contains mistakes 408 Loading the program 410 The dry run to check for setup mistakes 411 Cautiously running the first workpiece 412

INDEX 415